ZENDURE

Satellite Battery

Satellite Battery B4400/A400

User Manual

Scan for more information about Satellite Battery

Safety Notice

Please read all instructions and warnings carefully before using the device. Failure to follow these instructions may result in fire, electric shock, or other injuries.

- Do not disassemble, modify, or repair the device yourself. Contact Zendure Support for assistance.
- Do not expose the device to water, fire, or extreme temperatures.
- Keep the device out of the reach of children and pets.
- Use only Zendure-approved accessories.
- Ensure proper ventilation during operation.
- Dispose of the device according to local regulations.

Specifications

Model	B4400/A400	B4400/A400
Energy Capacity	4400Wh	4400Wh
Rated Power	2400W	2400W
Peak Power	4800W (10s)	4800W (10s)
Battery Type	LiFePO4	LiFePO4
Cycle Life	6000 cycles to 80% capacity	6000 cycles to 80% capacity
Dimensions (W×H×D)	450×280×350mm	450×280×350mm
Weight	45kg	45kg
Protection Rating	IP65	IP65
Operating Temperature	-20°C to 45°C	-20°C to 45°C

Package Contents

- Satellite Battery ×1
- Quick Start Guide ×1
- Safety Guidelines
- Cables
  - Power Cable ×1
  - Communication Cable ×1
  - Parallel Cable ×1
  - Connection Cable for Satellite Battery ×1
  - Connection Cable for Power Station ×1
- Tools
  - Allen Wrench ×1
  - Screwdriver ×1

Product Overview

1. Power Button
2. Display Screen
3. Output Ports
4. Input Ports
5. Handle
6. Wheels
7. Ventilation Grille
8. Expansion Port
9. Communication Port
10. Parallel Port

Getting Started

Charging

1. Connect the power cable to the input port.
2. Plug the other end into a wall outlet.
3. The display will show the charging status.
4. Charging time: approximately 4 hours from 0% to 100%.

Powering On

Press and hold the power button for 3 seconds. The display will light up and show the battery level.

Powering Off

Press and hold the power button for 3 seconds until the display turns off.

Connecting to a Power Station

1. Ensure both devices are powered off.
2. Connect the connection cable for satellite battery to the expansion port of the satellite battery.
3. Connect the other end to the expansion port of the power station.
4. Power on the power station first, then the satellite battery.
5. The power station will automatically detect the satellite battery.

Parallel Connection

Up to 4 satellite batteries can be connected in parallel.

1. Power off all devices.
2. Connect the parallel cable between the parallel ports of each satellite battery.
3. Power on the primary power station first.
4. Power on the satellite batteries.
5. The system will automatically configure the parallel connection.

Maintenance

- Clean the device with a dry cloth. Do not use water or chemical cleaners.
- Check the ventilation grille regularly and remove any dust or debris.
- Store the device in a cool, dry place when not in use.
- Charge the battery every 6 months during storage.

Troubleshooting

Problem	Solution
Device will not power on	Check if the battery is charged. Charge for at least 4 hours.
Display shows error code	Restart the device. If the error persists, contact support.
Slow charging	Ensure the power cable is connected properly and the wall outlet is working.
Not detected by power station	Check the connection cable and ensure both devices are powered on.

Warranty

The Satellite Battery is covered by a 2-year limited warranty from the date of purchase. The warranty does not cover damage caused by misuse, accidents, or unauthorized modifications.

Contact Us

For technical support or warranty claims, please contact Zendure Support at support@zendure.com or visit our website at www.zendure.com.

概述

产品介绍

感谢您选择 Zendure 卫星电池。本手册将帮助您安全地安装、操作和维护您的设备。

主要特点

- 高容量储能
- 模块化设计，可扩展
- 智能电池管理系统
- 多重保护功能
- 易于安装和维护

技术规格

型号	B4400/A400	B4400/A400
储能容量	4400Wh	4400Wh
额定功率	2400W	2400W
峰值功率	4800W (10s)	4800W (10s)
电池类型	LiFePO4	LiFePO4
循环寿命	6000次循环至80%容量	6000次循环至80%容量
尺寸 (宽×高×深)	450×280×350mm	450×280×350mm
重量	45kg	45kg
防护等级	IP65	IP65
工作温度	-20°C 至 45°C	-20°C 至 45°C

包装内容

- 卫星电池 ×1
- 快速入门指南 ×1
- 安全须知
- 线缆
  - 电源线 ×1
  - 通信线 ×1
  - 并联线 ×1
  - 卫星电池连接线 ×1
  - 电源站连接线 ×1
- 工具
  - 内六角扳手 ×1
  - 螺丝刀 ×1

产品概览

1. 电源按钮
2. 显示屏
3. 输出端口
4. 输入端口
5. 手柄
6. 轮子
7. 通风格栅
8. 扩展端口
9. 通信端口
10. 并联端口

开始使用

充电

1. 将电源线连接到输入端口。
2. 将另一端插入墙壁插座。
3. 显示屏将显示充电状态。
4. 充电时间：从0%到100%约4小时。

开机

长按电源按钮3秒。显示屏将亮起并显示电池电量。

关机

长按电源按钮3秒，直到显示屏关闭。

连接电源站

1. 确保两台设备均已关机。
2. 将卫星电池连接线连接到卫星电池的扩展端口。
3. 将另一端连接到电源站的扩展端口。
4. 先开启电源站，然后开启卫星电池。
5. 电源站将自动检测卫星电池。

并联连接

最多可并联4个卫星电池。

1. 关闭所有设备。
2. 将并联线连接在每个卫星电池的并联端口之间。
3. 先开启主电源站。
4. 开启卫星电池。
5. 系统将自动配置并联连接。

维护保养

- 用干布清洁设备。请勿使用水或化学清洁剂。
- 定期检查通风格栅，清除灰尘或杂物。
- 不使用时将设备存放在阴凉干燥处。
- 存放期间每6个月为电池充电一次。

故障排除

问题	解决方案
设备无法开机	检查电池是否充电。充电至少4小时。
显示屏显示错误代码	重启设备。如果错误持续，请联系支持。
充电缓慢	确保电源线连接正确且墙壁插座正常。
未被电源站检测到	检查连接线并确保两台设备均已开机。

保修

卫星电池自购买之日起享有2年有限保修。保修不涵盖因滥用、事故或未经授权的改装造成的损坏。

联系我们

如需技术支持或保修索赔，请联系 Zendure 支持团队 support@zendure.com 或访问我们的网站 www.zendure.com。

概要

製品紹介

Zendure サテライトバッテリーをお買い上げいただきありがとうございます。このマニュアルは、本機を安全にインストール、操作、メンテナンスするのに役立ちます。

主な特徴

- 大容量エネルギー貯蔵
- モジュール設計、拡張可能
- インテリジェントバッテリー管理システム
- 多重保護機能
- 簡単な設置とメンテナンス

技術仕様

モデル	B4400/A400	B4400/A400
エネルギー容量	4400Wh	4400Wh
定格出力	2400W	2400W
ピーク出力	4800W (10s)	4800W (10s)
バッテリータイプ	LiFePO4	LiFePO4
サイクル寿命	6000サイクルで80%容量	6000サイクルで80%容量
寸法 (幅×高×奥行)	450×280×350mm	450×280×350mm
重量	45kg	45kg
保護等級	IP65	IP65
動作温度	-20°C ～ 45°C	-20°C ～ 45°C

同梱物

- サテライトバッテリー ×1
- クイックスタートガイド ×1
- 安全ガイドライン
- ケーブル
  - 電源ケーブル ×1
  - 通信ケーブル ×1
  - パラレルケーブル ×1
  - サテライトバッテリー接続ケーブル ×1
  - パワーステーション接続ケーブル ×1
- 工具
  - 六角レンチ ×1
  - ドライバー ×1

製品概要

1. 電源ボタン
2. ディスプレイ画面
3. 出力ポート
4. 入力ポート
5. ハンドル
6. ホイール
7. 通気グリル
8. 拡張ポート
9. 通信ポート
10. パラレルポート

はじめに

充電

1. 電源ケーブルを入力ポートに接続します。
2. もう一方の端をコンセントに差し込みます。
3. ディスプレイに充電状態が表示されます。
4. 充電時間：0%から100%まで約4時間。

電源オン

電源ボタンを3秒間長押しします。ディスプレイが点灯し、バッテリー残量が表示されます。

電源オフ

ディスプレイが消えるまで電源ボタンを3秒間長押しします。

パワーステーションへの接続

1. 両方のデバイスの電源がオフになっていることを確認します。
2. サテライトバッテリー接続ケーブルをサテライトバッテリーの拡張ポートに接続します。
3. もう一方の端をパワーステーションの拡張ポートに接続します。
4. パワーステーションを先に電源オンにし、次にサテライトバッテリーを電源オンにします。
5. パワーステーションが自動的にサテライトバッテリーを検出します。

パラレル接続

最大4台のサテライトバッテリーを並列接続できます。

1. すべてのデバイスの電源をオフにします。
2. パラレルケーブルを各サテライトバッテリーのパラレルポート間に接続します。
3. 主パワーステーションを先に電源オンにします。
4. サテライトバッテリーの電源をオンにします。
5. システムが自動的にパラレル接続を構成します。

メンテナンス

- 乾いた布で本機を清掃してください。水や化学クリーナーは使用しないでください。
- 通気グリルを定期的に点検し、ほこりや異物を除去してください。
- 使用しないときは、本機を涼しく乾燥した場所に保管してください。
- 保管中は6か月ごとにバッテリーを充電してください。

トラブルシューティング

問題	解決策
電源が入らない	バッテリーが充電されているか確認してください。少なくとも4時間充電してください。
ディスプレイにエラーコードが表示される	本機を再起動してください。エラーが続く場合はサポートにお問い合わせください。
充電が遅い	電源ケーブルが正しく接続されており、コンセントが機能していることを確認してください。
パワーステーションに検出されない	接続ケーブルを確認し、両方のデバイスの電源がオンになっていることを確認してください。

保証

サテライトバッテリーは、購入日から2年間の限定保証が適用されます。保証は、誤用、事故、または無許可の改造による損害には適用されません。

お問い合わせ

技術サポートまたは保証請求については、Zendure サポート support@zendure.com までご連絡いただくか、当社ウェブサイト www.zendure.com をご覧ください。

概述

产品介绍

感谢您选择 Zendure 卫星电池。本手册将帮助您安全地安装、操作和维护您的设备。

主要特点

- 高容量储能
- 模块化设计，可扩展
- 智能电池管理系统
- 多重保护功能
- 易于安装和维护

技术规格

型号	B4400/A400	B4400/A400
储能容量	4400Wh	4400Wh
额定功率	2400W	2400W
峰值功率	4800W (10s)	4800W (10s)
电池类型	LiFePO4	LiFePO4
循环寿命	6000次循环至80%容量	6000次循环至80%容量
尺寸 (宽×高×深)	450×280×350mm	450×280×350mm
重量	45kg	45kg
防护等级	IP65	IP65
工作温度	-20°C 至 45°C	-20°C 至 45°C

包装内容

- 卫星电池 ×1
- 快速入门指南 ×1
- 安全须知
- 线缆
  - 电源线 ×1
  - 通信线 ×1
  - 并联线 ×1
  - 卫星电池连接线 ×1
  - 电源站连接线 ×1
- 工具
  - 内六角扳手 ×1
  - 螺丝刀 ×1

产品概览

1. 电源按钮
2. 显示屏
3. 输出端口
4. 输入端口
5. 手柄
6. 轮子
7. 通风格栅
8. 扩展端口
9. 通信端口
10. 并联端口

开始使用

充电

1. 将电源线连接到输入端口。
2. 将另一端插入墙壁插座。
3. 显示屏将显示充电状态。
4. 充电时间：从0%到100%约4小时。

开机

长按电源按钮3秒。显示屏将亮起并显示电池电量。

关机

长按电源按钮3秒，直到显示屏关闭。

连接电源站

1. 确保两台设备均已关机。
2. 将卫星电池连接线连接到卫星电池的扩展端口。
3. 将另一端连接到电源站的扩展端口。
4. 先开启电源站，然后开启卫星电池。
5. 电源站将自动检测卫星电池。

并联连接

最多可并联4个卫星电池。

1. 关闭所有设备。
2. 将并联线连接在每个卫星电池的并联端口之间。
3. 先开启主电源站。
4. 开启卫星电池。
5. 系统将自动配置并联连接。

维护保养

- 用干布清洁设备。请勿使用水或化学清洁剂。
- 定期检查通风格栅，清除灰尘或杂物。
- 不使用时将设备存放在阴凉干燥处。
- 存放期间每6个月为电池充电一次。

故障排除

问题	解决方案
设备无法开机	检查电池是否充电。充电至少4小时。
显示屏显示错误代码	重启设备。如果错误持续，请联系支持。
充电缓慢	确保电源线连接正确且墙壁插座正常。
未被电源站检测到	检查连接线并确保两台设备均已开机。

保修

卫星电池自购买之日起享有2年有限保修。保修不涵盖因滥用、事故或未经授权的改装造成的损坏。

联系我们

如需技术支持或保修索赔，请联系 Zendure 支持团队 support@zendure.com 或访问我们的网站 www.zendure.com