
MP Phase 1
MP Phase 2
MP Phase 3
Essential loads
Loads
Generator
Grid
L1 / L2 / L3
L1 / L2 / L3
L1 / L2 / L3
GND
GND
GND
ESS48-2U-L LEP Battery
ESS48-2U-L LEP Battery
GND
Optional: Victron Energymeter
VM-3P75CT
VE.Bus
VE.Can
BMS-CAN
Cerbo GX